

Tabla de Todos los Modelos, Tamaños, Terminaciones y Capuchas Rev. 12/5/16

Nota: Si Usted no conoce el tamaño de su abrazadera Rovner, el mismo se encuentra estampado en el interior de la abrazadera.

- = Indica Terminación Dual Tone, todos los otros terminación Polished Alloy
- = Indica los tamaños mas comunes para boquillas de pasta
- = Tamaño de las capuchas actualizado en 11/2016. El tamaño antiguo figura entre parentesis.

Mouthpiece Type	Classic Models								Next Generation Models									
	Dark	Cap	Light	Cap	MKIII	Cap	Versa	Cap	Star Series	Cap	Legacy	Cap	Versa-X	Cap	Platinum	Cap	Van Gogh	Cap
Bb German String & Eb Clarinet (HR)	1E	1	L-1E (L-4)	1	C-1E	7	V-1E	2 [7]	SS-1E	1A [8]	LG-1E	1A [1]	X-1E	7	P-1E	6	VG-1E	1
Alto Std. / Tenor & Bari X. Slim (Metal)	1M	6 [5]	L-1M (L-11)	6 [5]	C-1M	6 [5]			SS-1M	6A	LG-1M	6	X-1M	5	P-1M	6A		
Alto Sax (Metal)							V-1M(A)	2A [5]										
Tenor & Bari X. Slim (Metal)							V-1M(T)	2A [5]										
Soprano Slim / Alto X. Slim (Metal)	1MB	6																
Soprano Sax (Metal)	1MD	8																
Soprano Slim (Metal)	1MS	8	L-1MS (L-2)	8														
Soprano X. Slim (Metal)	1MVS	8A [8]																
Bb Clarinet (HR)	1R	7	L-1R (L-5)	7	C-1R	7	V-1R	7	SS-1R	1	LG-1R	1	X-1R	7	P-1R	6 [1A]	VG-1R	7
Alto Std. / Tenor Slim (HR)	1RL	7	L-1RL (L-6)	7	C-1RL	7	V-1RL(A)	7	SS-1RL	1	LG-1RL	7	X-1RL	3 [7]	P-1RL	1A [2A]	VG-1RL(A)	7
Tenor Slim (HR)							V-1RL(T)	3										
Alto Slim (HR)	1RR	7																
Soprano Sax (HR)	1RVS	1	L-1RVS (L-3)	1	C-1RVS	1	V-1RVS	1 [7]	SS-1RVS	8			X-1RVS	1 [7]	P-1RVS	8A	VG-1RVS	1
Soprano Std. / Soprano Slim (HR)	1RXS	8			C-1RXS	8	V-1RXS	8										
Tenor Slim / Alto LG. (Metal)	2M	5	L-2M (L-12)	5	C-2M	5			SS-2M	6	LG-2M	6 [5A]	X-2M	5	P-2M	6A		
Alto Slim (Metal)							V-2M(A)	2A [2]										
Tenor Slim (Metal)							V-2M(T)	5										VG-2M(T)
Tenor Std. / Bari Slim (HR)	2R	3	L-2R (L-8)	3	C-2R	3	V-2R	4	SS-2R	3A	LG-2R	3	X-2R	4	P-2R	5 [2]	VG-2R	3
Bari Slim / Alto LG. (HR)	2RBL	3	L-2RBL (L-7.5)	3														
Alto Clarinet (HR)	2RS	3	L-2RS (L-7)	3														
Tenor Std. / Bari Slim / Alto LG. (Metal)	3ML	5	L-3ML (L-13)	5	C-3ML	5			SS-3ML	5A	LG-3ML	5A	X-3ML	3A	P-3ML	5A [2A]		
Alto LG. (Metal)							V-3ML(A)	5 [3A]										
Tenor Std. / Bari Slim (Metal)							V-3ML(T)	5 [3A]										VG-3ML(T)
Tenor Large (Metal)	3ML-NY	5							SS-3ML-NY	5A								
Baritone Sax (Metal)	3MVL	5 [3]																
Baritone Sax (HR)	3R	4	L-3R (L-9)	4	C-3R	4	V-3R	4	SS-3R	4A [4]	LG-3R	4	X-3R	4	P-3R	4A	VG-3R	4
Bass Clarinet (HR)	3RL	4	L-3RL (L-10)	4	C-3RL	4	V-3RL	4	SS-3RL	4	LG-3RL	4	X-3RL	4	P-3RL	4A	VG-3RL	4
Bass Sax / Large Bari Sax (HR)	4R	4																
Contra Bass Clarinet (HR)	4RL	4																
Contra Alto Clarinet (HR)	4RS	4																
Alto Sax (Metal)							V-RAM	2	SS-RAM	6A [6]					P-RAM	6A		
Soprano Sax (Metal)							V-RSM	8										
Tenor Sax (Metal)							V-RTM	5	SS-RTM	5A	LG-RTM	5A			P-RTM	6A		

Boquillas de Marca – Tamaños Recomendados - Generic to Bari

Manufacturer	Manufacturer Model	Instrument	Composition	Dark	Light	Mark III	Versa	Star Series	Legacy	Versa-x	Platinum	Van Gogh
Most Common Fit	GENERIC	Eb Clarinet (soprano)	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
Most Common Fit	GENERIC	Bb Clarinet (soprano)	hard rubber	1R	L-1R (L5)	C-1R	V-1R	SS-1R	LG-1R	X-1R	P-1R	VG-1R
Most Common Fit	German String Style	Bb Clarinet (soprano)	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
Most Common Fit	GENERIC	Eb Clarinet (alto)	hard rubber	2RS	L-2RS (L7)							
Most Common Fit	GENERIC	Bb Clarinet (bass)	hard rubber	3RL	L-3RL (L10)	C-3RL	V-3RL	SS-3RL	LG-3RL	X-3RL	P-3RL	VG-3RL
Most Common Fit	GENERIC	Eb Clarinet (contra alto)	hard rubber	4RS								
Most Common Fit	GENERIC	Bb Clarinet (contra bass)	hard rubber	4RL								
Most Common Fit	GENERIC	Sopranino Sax	hard rubber	1RXS		C-1RXS	V-1RXS					
Most Common Fit	GENERIC	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
Most Common Fit	GENERIC	Soprano Sax	metal	N.A.								
Most Common Fit	GENERIC	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
Most Common Fit	GENERIC	Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
Most Common Fit	GENERIC	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
Most Common Fit	GENERIC	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
Most Common Fit	GENERIC	Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
Most Common Fit	GENERIC	Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
Most Common Fit	GENERIC	Bass Sax	hard rubber	4R								
ARB		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
ARB		Soprano Sax	metal	1MVS								
ARB		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
ARB		Alto Sax	metal	1MB								
ARB		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
ARB		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
ARB		Baritone Sax	metal	1M	L-1M (L11)	C-1M	V-1M(T)	SS-1M	LG-1M	X-1M	P-1M	
AM MOUTHPIECES	THE ARAS	Soprano Sax	metal	1M	L-1M (L11)	C-1M	V-1M (T)	SS-1M	LG-1M	X-1M	P-1M	
AM MOUTHPIECES	THE LUNA	Soprano Sax	metal	1M	L-1M (L11)	C-1M	V-1M (T)	SS-1M	LG-1M	X-1M	P-1M	
AM MOUTHPIECES	THE KATANA	Soprano Sax	metal	1M	L-1M (L11)	C-1M	V-1M (T)	SS-1M	LG-1M	X-1M	P-1M	
AM MOUTHPIECES	THE ARAS	Alto Sax	metal	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
AM MOUTHPIECES	THE LUNA	Alto Sax	metal	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
AM MOUTHPIECES	THE KATANA	Alto Sax	metal	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
AM MOUTHPIECES	COCOBOLO WOOD	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL (A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL (A)
AM MOUTHPIECES	THE ARAS	Tenor Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL (T)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL (T)
AM MOUTHPIECES	THE LUNA	Tenor Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL (T)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL (T)
AM MOUTHPIECES	THE LUNA	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
AM MOUTHPIECES	THE KATANA	Tenor Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL (T)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL (T)
AM MOUTHPIECES	THE KATANA	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
AM MOUTHPIECES	COCOBOLO WOOD	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
AM MOUTHPIECES	THE ARAS	Baritone Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL (T)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL (T)
AM MOUTHPIECES	THE LUNA	Baritone Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL (T)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL (T)
AM MOUTHPIECES	THE KATANA	Baritone Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL (T)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL (T)
AM MOUTHPIECES	COCOBOLO WOOD	Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
BABBIT		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
BABBIT		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
BABBIT		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
BABBIT		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
BABBIT		Baritone Sax	hard rubber	4RL								
BABBIT		Bass Sax	hard rubber	4R								
BARI		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
BARI		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
BARI		Alto Sax	metal	1MB								
BARI		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
BARI		Tenor Sax	metal	1M	L-1M (L11)	C-1M	V-1M(T)	SS-1M	LG-1M	X-1M	P-1M	
BARI		Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)

Boquillas de Marca – Tamaños Recomendados - Barone to Drake

Manufacturer	Manufacturer Model	Instrument	Composition	Dark	Light	Mark III	Versa	Star Series	Legacy	Versa-x	Platinum	Van Gogh
BARONE		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
BARONE		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
BARONE		Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
BARONE		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
BARONE		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
BEECHLER		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
BEECHLER		Soprano Sax	metal	1MVS								
BEECHLER		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
BEECHLER		Alto Sax	metal	1MB								
BEECHLER		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
BEECHLER		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
BEECHLER		Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
BERG LARSEN		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
BERG LARSEN		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
BERG LARSEN		Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
BERG LARSEN		Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
BERG LARSEN		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-1M	VG-2M(T)
BERG LARSEN		Baritone Sax	hard rubber	2RBL	L-2RBL (L7.5)							
BERG LARSEN		Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
BILGER		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
BILGER		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
BILGER		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
BRILHART		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
BRILHART		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
BRILHART		Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
BRILHART	Slim	Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
BRILHART		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
BRILHART		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
BRILHART		Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
BRILHART		Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
CARAVAN		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
CARAVAN		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
CARAVAN		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
CARAVAN		Baritone Sax	hard rubber	4R								
CLAUDE LAKEY		Soprano Sax	metal	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
CLAUDE LAKEY		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
CLAUDE LAKEY		Alto Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
CLAUDE LAKEY		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
CLAUDE LAKEY		Tenor Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
COUF		Soprano Sax	hard rubber	1RXS		C-1RXS	V-1RXS					
COUF		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
COUF		Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
COUF		Baritone Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
DRAKE	SON OF SLANT	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
DRAKE	VR JAZZ	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
DRAKE	NY JAZZ	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
DRAKE	VR CONTEMPORY	Alto Sax	hard rubber	1R	L-1R (L5)	C-1R	V-1R	SS-1R	LG-1R	X-1R	P-1R	VG-1R
DRAKE	VR JAZZ	Alto Sax	hard rubber	1R	L-1R (L5)	C-1R	V-1R	SS-1R	LG-1R	X-1R	P-1R	VG-1R
DRAKE	VR CONTEMPORY	Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL			P-1RL	
DRAKE	EDDIE DANIELS	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
DRAKE	J BERGONZI	Tenor Sax	hard rubber	2RBL	L-2RBL(L7.5)							
DRAKE	PETE CHRISTLIEB	Tenor Sax	hard rubber	1M	L-1M(L11)	C-1M		SS-1M			P-1M	
DRAKE	VRSST	Tenor Sax	hard rubber	1E	L-1E(L4)	C-1E		SS-1E			P-1E	
DRAKE	CONTEMPORY	Baritone Sax	hard rubber	2RBL	L-2RBL(L7.5)							

Boquillas de Marca – Tamaños Recomendados - Morgan to Precision Crafted

Manufacturer	Manufacturer Model	Instrument	Composition	Dark	Light	Mark III	Versa	Star Series	Legacy	Versa-x	Platinum	Van Gogh
MORGAN	"C"	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
MORGAN	"J"	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
MORGAN	"L&M"	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
MORGAN	"S"	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
MORGAN	VINTAGE 1C	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
MORGAN	"E"	Alto Sax	hard rubber	1R	L-1R (L5)	C-1R	V-1R	SS-1R	LG-1R	X-1R	P-1R	VG-1R
MORGAN	"C"	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
MORGAN	"L&M"	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
MORGAN	"S"	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
MORGAN	EXCALIBER	Alto Sax	hard rubber	1R	L-1R(L5)	C-1R	V-1R	SS-1R	LG-1R	X-1R	P-1R	VG-1R
MORGAN	4M	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
MORGAN	"E"	Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
MORGAN	"C"	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
MORGAN	"L&M"	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
MORGAN	"S"	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
MORGAN	"C"	Tenor Sax	hard rubber	2RBL	L-2RBL (L7.5)							
MORGAN	EXCALIBER	Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
MORGAN	"J"	Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
MORGAN	"C"	Baritone Sax	hard rubber	4R								
MORGAN	"S"	Baritone Sax	hard rubber	4R								
MORGAN	VINTAGE 9*	Baritone Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
MORGAN	"C"	Bass Sax	hard rubber	4R								
OTTO LINK		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
OTTO LINK		Soprano Sax	metal	1MVS								
OTTO LINK		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
OTTO LINK		Alto Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(A)	SS-3ML	LG-3ML	X-3ML	P-3ML	
OTTO LINK		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
OTTO LINK		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
OTTO LINK	"NY"	Tenor Sax	metal	3ML-NY				SS-3ML-NY				
OTTO LINK		Baritone Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
OTTO LINK		Baritone Sax	metal	3MVL								
PILLINGER		Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
PONZOL	VINTAGE	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
PONZOL	ALUMINUM	Soprano Sax	metal	1MB								
PONZOL	CUSTOM	Soprano Sax	metal	1MB								
PONZOL	STAINLESS	Soprano Sax	metal	1MB								
PONZOL	EBO	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
PONZOL	SILVER LINE	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
PONZOL	VINTAGE	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
PONZOL	GOLD BRASS	Alto Sax	metal	?								
PONZOL	ALUMINUM	Alto Sax	metal	2M	L-2M (L12)	C-2M	V-2M(A)	SS-2M	LG-2M	X-2M	P-2M	
PONZOL	CUSTOM	Alto Sax	metal	2M	L-2M (L12)	C-2M	V-2M(A)	SS-2M	LG-2M	X-2M	P-2M	
PONZOL	STAINLESS	Alto Sax	metal	2M	L-2M (L12)	C-2M	V-2M(A)	SS-2M	LG-2M	X-2M	P-2M	
PONZOL	EBO	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
PONZOL	SILVER LINE	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
PONZOL	VINTAGE	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
PONZOL	GOLD BRASS	Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(A)	SS-2M	LG-2M	X-2M	P-2M	
PONZOL	ALUMINUM	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
PONZOL	CUSTOM	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
PONZOL	STAINLESS	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
PONZOL	ALUMINUM	Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
PONZOL	CUSTOM	Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
PONZOL	STAINLESS	Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
PRECISION CRAFTED		Alto Sax	metal				V-RTM	SS-RTM	LG-RTM		P-RTM	
PRECISION CRAFTED		Tenor Sax	metal	1M	L-1M (L11)	C-1M	V-1M(T)	SS-1M	LG-1M	X-1M	P-1M	

Boquillas de Marca - Tamaños Recomendados - RIA to Runyon

Manufacturer	Manufacturer Model	Instrument	Composition	Dark	Light	Mark III	Versa	Star Series	Legacy	Versa-x	Platinun	Van Gogh
RIA		Soprano Sax	metal	1MS	L-1MS (L2)							
RIA		Alto Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(A)	SS-3ML	LG-3ML	X-3ML	P-3ML	
RIA		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
RICO ROYAL		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
RICO ROYAL		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
RICO ROYAL		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
RICO ROYAL		Baritone Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
ROUSSEAU		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
ROUSSEAU		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
ROUSSEAU		Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
ROUSSEAU		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
ROUSSEAU		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
ROUSSEAU		Baritone Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
ROVNER	G SERIES	Soprano Sax	hard rubber	1RXS		C-1RXS	V-1RXS					
ROVNER	WILKERSON	Soprano Sax	hard rubber	1RXS		C-1RXS	V-1RXS					
ROVNER	ALL	Soprano Sax	metal				V-RSM					
ROVNER	G SERIES	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
ROVNER	WILKERSON	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
ROVNER	ALL	Alto Sax	metal				V-RAM	SS-RAM			P-RAM	
ROVNER	G SERIES	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
ROVNER	WILKERSON	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
ROVNER	ALL	Tenor Sax	metal				V-RTM	SS-RTM	LG-RTM		P-RTM	
ROVNER	WILKERSON	Baritone Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
RPC		Baritone Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
RUNYON	CUSTOM	Bb Clarinet (soprano)	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	JAZZ	Bb Clarinet (soprano)	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	"XL"	Soprano Sax	hard rubber	1RXS		C-1RXS	V-1RXS					
RUNYON	CUSTOM	Soprano Sax	hard rubber	1RXS		C-1RXS	V-1RXS					
RUNYON	QUANTUM	Soprano Sax	hard rubber	1RXS		C-1RXS	V-1RXS					
RUNYON	"XL"	Soprano Sax	metal	1MS	L-1MS (L2)							
RUNYON	SMOOTH BORE	Soprano Sax	metal	1MS	L-1MS (L2)							
RUNYON	QUANTUM	Soprano Sax	metal	1RXS		C-1RXS	V-1RXS					
RUNYON	"88"	Alto Sax	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	CUSTOM	Alto Sax	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	JAZZ	Alto Sax	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	"XL"	Alto Sax	hard rubber	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
RUNYON	QUANTUM	Alto Sax	hard rubber	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
RUNYON	FINESSE	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
RUNYON	BIONIX	Alto Sax	hard rubber	1RR								
RUNYON	QUANTUM	Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
RUNYON	SMOOTH BORE	Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
RUNYON	"88"	Tenor Sax	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	CUSTOM	Tenor Sax	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	FINESSE	Tenor Sax	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	"XL"	Tenor Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
RUNYON	QUANTUM	Tenor Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
RUNYON	"22"	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
RUNYON	BIONIX	Tenor Sax	hard rubber	2RS	L-2RS (L7)							
RUNYON	"SR"	Tenor Sax	hard rubber	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
RUNYON	QUANTUM	Tenor Sax	metal	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
RUNYON	"XL"	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
RUNYON	SMOOTH BORE	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)

Boquillas de Marca - Tamaños Recomendados - Runyon to Tibbs

Manufacturer	Manufacturer Model	Instrument	Composition	Dark	Light	Mark III	Versa	Star Series	Legacy	Versa-x	Platinun	Van Gogh
RUNYON	QUANTUM	Baritone Sax	hard rubber	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	"88"	Baritone Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
RUNYON	CUSTOM	Baritone Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
RUNYON	QUANTUM	Baritone Sax	metal	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
RUNYON	SMOOTH BORE	Baritone Sax	metal	1E	L-1E (L4)	C-1E	V-1E	SS-1E	LG-1E	X-1E	P-1E	VG-1E
SELMER	SUPER SESSION	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
SELMER		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
SELMER		Soprano Sax	metal	1MS	L-1MS (L2)							
SELMER	SUPER SESSION	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
SELMER		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
SELMER		Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
SELMER	ARTIST	Alto Sax	metal	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
SELMER		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
SELMER		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
SELMER		Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
SELMER		Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
SELMER		Bass Sax	hard rubber	4R								
SR TECHNOLOGIES		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
SR TECHNOLOGIES		Soprano Sax	metal	1MS	L-1MS (L2)							
SR TECHNOLOGIES		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
SR TECHNOLOGIES		Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
SR TECHNOLOGIES		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
SR TECHNOLOGIES		Baritone Sax	hard rubber	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
SUGAL	LEIBMAN	Soprano Sax	metal				V-RSM					
SUGAL		Alto Sax	metal	2M	L-2M (L12)	C-2M	V-2M(A)	SS-2M	LG-2M	X-2M	P-2M	
SUGAL		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
SUGAL		Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
THEO WANNE	GAIA 2	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
THEO WANNE	DURGA 3	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
THEO WANNE	DURGA 3 BLUE ART	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
THEO WANNE	DURGA 3	Soprano Sax	metal	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
THEO WANNE	GAIA 2	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
THEO WANNE	DURGA 3	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
THEO WANNE	DURGA 3 BLUE ART	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
THEO WANNE	NY BROTHERS	Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
THEO WANNE	MINDI ABAIR	Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
THEO WANNE	AMBIKA 2	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	AMBIKA 2 BLUE ART	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	GAIA 2	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	GAIA 2 BLUE ART	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	SHIVA 2	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	SHIVA 2 BLUE ART	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	SLANT SIG	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	SLANT SIG BLUE ART	Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
THEO WANNE	GAIA 2	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
THEO WANNE	AMBIKA 2	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
THEO WANNE	SHIVA 2	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
THEO WANNE	DURGA 3	Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
TIBBS		Soprano Sax	metal	1MS	L-1MS (L2)							
TIBBS		Alto Sax	metal	2M	L-2M (L12)	C-2M	V-2M(A)	SS-2M	LG-2M	X-2M	P-2M	
TIBBS		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
TIBBS		Baritone Sax	metal	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	

Boquillas de Marca - Tamaños Recomendados - Vandoren to Zagar

Manufacturer	Manufacturer Model	Instrument	Composition	Dark	Light	Mark III	Versa	Star Series	Legacy	Versa-x	Platinum	Van Gogh
VANDOREN		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
VANDOREN	V-16	Soprano Sax	hard rubber				V-RTM	SS-RTM	LG-RTM		P-RTM	
VANDOREN		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
VANDOREN		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
VANDOREN		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
VANDOREN		Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
VANDOREN		Baritone Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
VANDOREN	SLIM LINE	Tenor Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(T)	SS-1RL	LG-1RL	X-1RL	P-1RL	
VANDOREN	SLIM LINE	Baritone Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
WARBURTON	A-SERIES	Soprano Sax	hard rubber	1MVS								
WARBURTON	J-SERIES	Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
WOLFE TAYNE		Alto Sax	metal	1M	L-1M (L11)	C-1M	V-1M(A)	SS-1M	LG-1M	X-1M	P-1M	
WOLFE TAYNE		Tenor Sax	metal	1M	L-1M (L11)	C-1M	V-1M(T)	SS-1M	LG-1M	X-1M	P-1M	
WOLFE TAYNE		Baritone Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
WOODWIND		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
WOODWIND		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
WOODWIND		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
WOODWIND		Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
WOODWIND		Bass Sax	hard rubber	4R								
YAMAHA		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
YAMAHA		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
YAMAHA		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
YAMAHA		Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
YANIGASAWA		Soprano Sax	hard rubber	1RVS	L-1RVS (L3)	C-1RVS	V-1RVS	SS-1RVS		X-1RVS	P-1RVS	VG-1RVS
YANIGASAWA		Soprano Sax	metal	1MVS								
YANIGASAWA		Alto Sax	hard rubber	1RL	L-1RL (L6)	C-1RL	V-1RL(A)	SS-1RL	LG-1RL	X-1RL	P-1RL	VG-1RL(A)
YANIGASAWA		Alto Sax	metal	2M	L-2M (L12)	C-2M	V-2M(A)	SS-2M	LG-2M	X-2M	P-2M	
YANIGASAWA		Tenor Sax	hard rubber	2R	L-2R (L8)	C-2R	V-2R	SS-2R	LG-2R	X-2R	P-2R	VG-2R
YANIGASAWA		Tenor Sax	metal	2M	L-2M (L12)	C-2M	V-2M(T)	SS-2M	LG-2M	X-2M	P-2M	VG-2M(T)
YANIGASAWA		Baritone Sax	hard rubber	3R	L-3R (L9)	C-3R	V-3R	SS-3R	LG-3R	X-3R	P-3R	VG-3R
YANIGASAWA		Baritone Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)
ZAGAR V-SERIES		Tenor Sax	metal	3ML	L-3ML (L13)	C-3ML	V-3ML(T)	SS-3ML	LG-3ML	X-3ML	P-3ML	VG-3ML(T)